


RPV599A Owner's Manual



THANK YOU

Thank you for your purchase of the RELM two-way portable radio. This easy-to-use radio adopts the latest advanced technology, providing reliable communication performance in today's demanding communications environment.

Before operating this radio, please read this manual carefully to be acquainted with its operation and features.

CONTENTS

User Safety, Training, and General Information	4
Compliance with RF Energy Exposure Standards	4
FCC Compliance	5
Precautions	5
Supplied Accessories	7
Charging The Battery	7
Installing/Removing Accessories	8
Battery	8
Unit with belt clip	8
Antenna	8
External Speaker Microphone	8
Belt Clip	9
Radio Controls	9
LCD Icons	11
Features and Operation	12
POWER	12
VOLUME	12
MONITOR	12
SELECT CHANNEL	12
SELECT SQUELCH LEVEL	12
RECEIVE	13
TRANSMIT	13
SELECT TRANSMIT POWER	13
CONNECT ID/DISCONNECT ID	13
CHANNEL SCAN	14
FREQUENCY REVERSE / TALK AROUND	15
DTMF SELECTIVE CALL	16
CODE SQUELCH	17
SELECTIVE CALLING	18
TWO-TONE SELECTIVE CALL	18
SELECTABLE CTCSS	18
AUTO-RESPONDER	18
CALL ALERT TONE	19
Care and Cleaning	19
Service	19

User Safety, Training, and General Information

READ THIS IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION BEFORE USING YOUR RELM HANDHELD PORTABLE TWO-WAY RADIO.

Compliance with RF Energy Exposure Standards

Your **RELM** two-way radio is designed and tested to comply with a number of national and international standards and guidelines (listed below) regarding human exposure to radio frequency electromagnetic energy. This radio complies with the IEEE (FCC) and ICNIRP exposure limits for occupational/controlled RF exposure environment at duty cycles of up to 50% talk-50% listen and should be used for occupational use only. In terms of measuring RF energy for compliance with the FCC exposure guidelines, your radio radiates measurable RF energy only while it is transmitting (during talking), not when it is receiving (listening) or in standby mode.

Note: The approved batteries supplied with this radio are rated for a 5-5-90 duty cycle (5% talk-5% listen-90% standby), even though this radio complies with the FCC occupational RF exposure limits at duty cycles of up to 50% talk.

Your RELM two-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J
- American National Standards Institute (ANS)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radio frequency Electromagnetic Fields in the Frequency Range from 3kHz to 300GHz, 1999
- Australian Communications Authority Radio communications (Electromagnetic Radiation-Human Exposure) Standard 1999 (applicable to wireless phones only)

Operational Instructions and Training Guidelines

To ensure optimal performance and compliance with the occupational/controlled environment RF energy exposure limits in the above standards and guidelines, users should transmit no more than 50% of the time and always adhere to the following procedures:

Transmit and Receive

To transmit (talk), push the Push-To-Talk (PTT) button; to receive, release the PTT button.

Hand-held radio operation

Hold the radio in a vertical position with the microphone one to two inches (2.5 to 5 cm) away from the lips.

Body-worn operation

- Always place the radio in a RELM approved clip, holder, holster, case, or body harness for this product. Use of non-RELM-approved accessories may exceed FCC RF exposure

guidelines.

- If you do not use a RELM approved body-worn accessory and are not using the radio in the intended use position in front of the face, then ensure the antenna and the radio are kept one inch (2.5 cm) from the body when transmitting.

Antennas & Batteries

- Use only RELM approved, supplied antenna or RELM approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the radio and may violate FCC regulations.
- Use only RELM approved, supplied batteries or RELM approved replacement batteries. Use of non-RELM-approved batteries may exceed FCC RF exposure guidelines.

Approved Accessories

For a list of RELM approved accessories, see the accessories page of this user manual or visit the following website which lists approved accessories: <http://www.RELM.com>

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Compliance

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 Canada.

FCC Requirements

Your radio must be properly licensed Federal Communications Commission prior to use. Your RELM Wireless dealer can assist you in meeting these requirements. Your dealer will program each radio with your authorized frequencies, signaling codes, etc., and will be there to meet your communications needs as your system expands.

Precautions

- Only qualified technicians are allowed to maintain this product.
- Do not use the transceiver or charge a battery in explosive areas such as coal gas, dust, steam, etc.

- Switch OFF the transceiver while refueling or parking at gas station.
- Do not modify or adjust this transceiver without permission.
- Do not expose the transceiver to direct sunlight over a long time, nor place it close to heating source.
- Do not place the transceiver in excessively dusty, humid areas, nor on unstable surfaces.

Safety: It is important that the operator is aware of and understands hazards common to the operation of any transceiver.


Supplied Accessories

Please carefully take the transceiver out of the box. We recommend that you confirm the items listed in the following table before discarding the box. If any items are missing or have been damaged during shipment, file a claim with the carrier immediately.

Item	Qty. (pcs)
Antenna	1
Belt clip	1
Screw set	1
External speaker-microphone jack cover	1
Locking bracket for speaker-microphone	1
Battery	1
Charger	1
Warranty card	1
Owner's Manual	1

Charging The Battery

The factory does not charge the battery before it is shipped. It must be charged before being used. Repeat charging and discharging for two or three times to optimize its charging capacity. When the battery voltage becomes low to the point the radio indicates low voltage (flashing led, no display...), the battery should be recharged or replaced with a charged battery.



- Slide the battery pack or transceiver with a battery back into the charger.
- Make sure the battery pack contacts make contact with the charging terminals.
- When the battery begins charging, the status LED is red; and when the battery is fully charged the status LED is green.

Battery Charging Notes

- If the radio is on during charging, the charging time will be prolonged.
- If the battery is fully charged, allow it to discharge some before re-installing into the charger. Overcharging it will reduce battery life and may cause damage.
- After the charging cycle is finished, remove the battery from the charger.
- If the battery does not retain a charge, the battery may need to be replaced.
- Do not “short” the battery terminals (short-circuit), dispose the battery in fire, nor disassemble the battery.


Installing/Removing Accessories

Battery

Unit without belt clip

Align the four slots on the battery cover with the tabs on the aluminum cover and then push up the battery until the latch on the cover bottom locks in place.

To remove the battery, release the latch located at the bottom of the radio and slide the battery away from the radio.




Unit with belt clip

Carefully lift up the end of the belt clip and align the four slots on the battery cover with the tabs on the aluminum cover

Push up the battery until the latch on the cover bottom locks in place.

To remove the battery, carefully lift up the end of the belt clip release the latch and slide the battery away from the radio.



Antenna

Position the antenna base on the radio connector and turn the antenna clockwise until it is firmly seated in place. To remove, turn the antenna counter-clockwise.

External Speaker Microphone


Remove the screw holding the Speaker/Microphone dust cover. Remove the dust cover and insert the Speaker/Microphone plugs into the speaker-microphone jacks. Affix the external

speaker-microphone with the retainer clip by using the supplied screw (3mm x 6mm). If the external speaker-microphone is not used, replace the dust cover.

Belt Clip

Using the supplied screws (2 pcs - 3mm x 8mm.), mount the belt clip to mounting holes in the rear case.

Radio Controls



(1) ANTENNA

(2) CHANNEL SELECTOR KNOB

Used to select channel and squelch level. In addition, it can be programmed by the dealer to delete undesired channels from scan list or to select a CTCSS frequency.

(3) LED INDICATOR

- Is red when transmitting
- Is green when receiving
- Flashes red when the battery voltage is low and approaching the cut-off point
- Flashes orange, when the radio receives proper DTMF or Two Tone decode signals.

(4) ON-OFF/VOLUME KNOB

Rotate the volume control knob clockwise to turn the unit “on” and fully counter clockwise to turn the unit “off”. Increase or decrease volume by adjusting the volume control accordingly.

(5) SPEAKER

(6) MICROPHONE

(7) LCD

Used to display channel and operation status.

(8) SCN KEY

Used to enable or disable the scan function.

(9) LO (low power) KEY

Used to toggle the transmit power mode from “high” to “low” or from “low” to “high”.

(10) TA KEY

Used to enable or disable FREQUENCY REVERSE/TALK AROUND feature.

(11) DIAL KEY

When the “store and send” feature is enabled, it is used to send codes; and when “auto-dial” feature is enabled, it is used to store, confirm, send or delete codes.

(12) KEYPAD

Used to enter, store or send DTMF codes.

(13) PTT BUTTON

Used to switch between transmit and receive mode.

(14) LAMP BUTTON

Used to turn “on” or “off” the LCD backlight. Press the [LAMP] button, the backlight will illuminate for about 5 seconds and then automatically turn off. During illuminating and pressing any key, except the [LAMP] button, the timer will re-start. To turn “off” the backlight, press the [LAMP] button again. .

(15) MONI BUTTON

Used to monitor the selected channels.

(16) EXTERNAL SPEAKER-MICROPHONE JACK


Used to connect with external the speaker-microphone, programming cable, or cloning cable.

(17) BELT CLIP

(18) BATTERY

(19) BATTERY LATCH

LCD Icons



- ① Appears when “low” power is selected.
- ② Appears when the selected channel is busy.
- ③ Appears when the [MONI] button is pressed to disable CTCSS/CDCSS.
- ④ Appears when the [MONI] button is pressed to switch the speaker on.
- ⑤ Appears when the selected channel is in the scan list. The radio only scans channels in the scan list.
- ⑥ Appears in scan mode.
- ⑦ Displays the selected channel number, squelch level or DTMF code. When selective call is enabled, messages received are also displayed here.

Features and Operation

POWER

To turn on the power, turn the **On-Off/VOL** knob clockwise until a “click” is heard (the tone also can be programmed as “beeps”), and characters will be displayed on LCD. To turn off the power, turn the **On-Off/VOL** knob counterclockwise until a “click” is heard.

VOLUME

Press **[MONI]** button to monitor background noise, and at the same time turn **On-Off/VOL** knob to adjust the volume to a comfortable level.

MONITOR

There are four ways the monitor function can be configured. Your dealer can program one of the following four monitor modes:

- OFF – No audio is heard when the momentary monitor key is pressed.
- Monitor Momentary – When using any tone mode decode and a receive signal is present with an incompatible tone or no tone, audio can be heard when the momentary monitor key is pressed.
- Monitor Lock – Same as Monitor Momentary, but the momentary monitor key toggles the audio function “on” or “off”.
- SQ OFF Momentary – Receiver audio is heard when the momentary monitor key is pressed.


SELECT CHANNEL

Turn the channel selector knob to change the channel. The channel number is displayed on LCD. Turn the knob clockwise, channel number will increase; and turn counter clockwise, channel number will decrease. The factory or dealer programs the channel frequencies of each channel.

SELECT SQUELCH LEVEL

Hold down the **[MONI]** button, and then press the **[LO]** key. The current squelch level code is displayed on the LCD as shown below. Turn the **CHANNEL SELECTOR** knob to select the squelch level and press any key, except the **[LAMP]** button, to store the setting. The LCD returns to the origin display.

Note: If the squelch level is set too high, you may not efficiently receive weak signals; if the level is set too low, you may hear a constant white noise, hear a sputtering noise, or hear unwanted noises.



RECEIVE

CTCSS /CDCSS/ DTMF/Two-Tone functions are programmed by the factory or your dealer. When signaling tones have been programmed, only channels with the same frequency and signaling tones can be heard. If tone signaling is not used, then all conversations on your selected channel can be heard.

TRANSMIT

Before transmitting, verify there is no channel activity. Push the **PTT** button and speak clearly into the microphone (mouth is 1 – 2 inches away from the microphone); or push a key on the keypad to transmit a DTMF tone. When the **PTT** button is released, the radio returns to receive mode.

NOTE:

- If your dealer has enabled Busy Channel Lockout feature and the selected channel is busy, when pressing the **[PTT]** button, the radio will sound an alert tone and the transmission is prohibited.
- When pressing the **[PTT]** button, the radio will check its battery voltage. If the battery voltage is lower than the “low battery” threshold value, the red LED flashes. If the voltages drops further, the radio stops transmitting and an alert sounds. In this condition, recharge or replace the battery with a charged battery.
- When continuous transmission time exceeds the preset time of the “Time-Out-Timer” (programmed by the dealer), the radio stops transmission and an alert sounds. The unit then returns to the receive mode. Also, a “Transmit Warning” alert tone can be programmed by the dealer to warn the end user that the transmission time is becoming long.

SELECT TRANSMIT POWER

If transmit power (programmed by the dealer) is set to “high” on any given channel, pressing the **[LO]** key will toggle the transmit power modes between “high” and “low”. When in low power mode, “Lo” appears on the LCD. Since using low transmit power mode can save battery life and decreases potential interference to others, low transmit power mode should be selected when the communication quality can be guaranteed.

NOTE:

- If “high” transmit power is prohibited on the current channel and “Lo” is displayed on LCD, when pressing **[LO]**, an alert tone of wrong operation will be heard and the transmit power will remain “low”.
- The operation of switching a channel from “high” transmit power mode to “low” transmit power mode will switch all channels from “high” transmit power mode to “low” transmit power mode.

CONNECT ID/DISCONNECT ID

When the radio is connecting or disconnecting to a repeater, a connect ID or disconnect ID (programmed by your dealer) can be sent. One of the following methods can be configured:

To transmit a connect ID:

- Method 1: Press the [PTT] button, the connect ID is transmitted.
- Method 2: While pressing the [PTT] button, press the [DIAL] key and then the [*] key, the connect ID is transmitted.

To transmit a disconnect ID:

- Method 1: Release the [PTT] button, the disconnect ID is transmitted.
- Method 2: While pressing the [PTT] button, press the [DIAL] key and then the [*] key, the disconnect ID is transmitted.

CHANNEL SCAN

Press [SCN], the radio begins scanning in ascending order from the current channel and “SCAN” appears on the LCD. To stop scanning, press [SCN] again.

■ SCAN OPERATION

When the radio stops on a busy channel, the scan function can be restarted according to the restart mode, which can be programmed by the dealer as **carrier-operated scan** or **time-operated scan**.


- **Carrier Operate** – Scan stops on a receiving channel until there is no activity; while inactive, the unit remains on the channel for the predetermined “Dropout Delay Time” (programmed by the dealer) before it resumes scanning.
- **Time Operate** – Scan stops on the receiving channel for only the predetermined “Dropout Delay Time” (programmed by the dealer) before it resumes scanning. The radio will begin scanning other channels even if the channel is still busy.

■ PRIORITY SCAN

If your dealer has programmed a priority channel, the radio will periodically sample the priority channel when it scans non-priority channels. When it detects any activity on the priority channel, the radio switches to the priority channel. When a priority channel is selected, “P” appears on the LCD.

■ CHANNEL DELETE

This feature allows you to delete undesired channels from the scan list. Select the channels to be deleted by using the channel selector knob in the non-scan mode. Holding down the [MONI] button and pressing the [SCN] key will toggle the selected channel between ADD and DELETE.



When the current channel is in scan list, “A” is displayed on the LCD.

DELETE

ADD


■ SCAN REVERT CHANNEL

The “Scan Revert Channel” feature (programmed by the dealer) allows you to transmit on a


predetermined channel while responding to or initiating a call while in the scan mode. When pressing the **[PTT]** button, the radio stops scanning and transmits on the “revert” channel.

FREQUENCY REVERSE / TALK AROUND

Your dealer can program the “Frequency Reverse” or “Talk Around” feature. If communications between radios are disrupted because of a long distance from the repeater, frequency reverse feature can be used to re-establish communications to another radio. When the “frequency reverse” feature is enabled, the transmit frequency and receive frequency will be reversed. At the same time, the corresponding CTCSS/CDCSS encode and decode tones will also be reversed. To enable or disable the “Frequency Reverse” feature, press the **[TA]** key.



If “Talk Around” is programmed, the TX frequency can be changed to be the same as the RX frequency. The CTCSS/CDCSS encode and decode tones change respectively. To enable or disable the “Talk Around” feature, press the [TA] key.



DTMF SELECTIVE CALL

■ MANUAL DIAL

While pressing the [PTT] button, press the DTMF keys to transmit the corresponding DTMF tones. The DTMF tones can be heard when a key is pressed. The radio can be programmed by the dealer to continue transmitting for 2 seconds after the [PTT] button is released. Therefore, in the 2 seconds, a DTMF code can be transmitted without pressing the [PTT] button. The [A], [B], [C] and [D] keys can be programmed as active or inactive DTMF keys.

■ STORE AND DIAL

If the dealer enables this feature, a DTMF code with up to 16 digits can be sent when the [DIAL] key is pushed.


- If [A], [B], [C] and [D] keys have been set as inactive in the manual dial mode, these keys still can be used in this feature.
- The “[D]” key can be programmed as a null tone (delay) by the dealer. (i.e., the “D” tone is not transmitted, it only represents a pause time.)

■ AUTO-DIAL

This function is enabled or disabled by the dealer.

STORING A DTMF CODE

One DTMF code with a maximum of 16 digits can be stored in any one of the ten numbered keys, [0]-[9]. Press the [DIAL] key and then press the [#] key. The LCD display is shown below. Enter the code to be stored (16 digits maximum) with the keypad, and press the [DIAL] key. Select a numbered key [0]-[9] to store the code into the memory location.



- If [A], [B], [C] and [D] keys have been set as inactive in the manual dial mode, these keys still can be used in this feature.
- If an incorrect digit was entered, press the [MONI] button and re-enter the whole number.
- To exit the tone entry mode, press the [PTT], [SCN], [TA], or [LO] key.

CONFIRM A STORED DTMF CODE

Press the [DIAL] key and then press the [*] key. The LCD display is shown below. Select a numbered key [0]-[9], the location where the DTMF code is stored. The stored code scrolls on LCD and corresponding DTMF tone is heard. To return to the original display, press any key.




SENDING A DTMF CODE

To transmit a stored DTMF code, press the [DIAL] key and the memory location [0]-[9]. The code is displayed on LCD during the transmission.

DELETE A STORED DTMF CODE

To delete a code, press the [DIAL] key and press the [D] key. The LCD display is shown below. Select the memory location [0]-[9]. To cancel this operation, press any key other than [0]-[9].



RE-DIAL

Pressing the [DIAL] key twice will transmit the last sent DTMF code. The code is displayed on LCD during the transmission.

NOTE: The Re-dial memory is deleted when the radio is turned off.

CODE SQUELCH

The dealer can program the “code squelch” signaling feature. If this feature is enabled and the received code is the same as the radio ID code (3-10 digits), squelch opens. If the dealer enables the “Auto-Responder” and “Call Alert Tone” feature, it can be used with Code Squelch signaling; but when Group Call is enabled, the “Auto- Responder” feature is inactive.

To send a call, hold down the [PTT] button and enter the ID code or Group Code by the keypad. The “store and send” or “auto-dial” feature can be used to send codes. When transmission ends, the radio returns to normal operation.

Note: The “Code Squelch” feature cannot be used with the “selective call” feature on the same channel.

SELECTIVE CALLING

The dealer can program the Selective Calling feature. This feature is similar to code squelch, but it is used to transmit or receive a combination message (maximum with 5 digits). The format is:

ID code (3 digits) +1 intermediate code +message code (maximum with 5 digits)

When the radio receives a DTMF code, the speaker is switched on and the following respective messages appears on the LCD:

- When the radio receives its ID code, a “C” appears on the LCD
- When the radio receives a group code, an “A” appears on the LCD.
- When there is no message code, “NO DATA” appears on the LCD.

To send a call, hold down the **[PTT]** button and enter the DTMF code by the keypad. The “store and send” or “auto-dial” feature can be used to send codes. When transmission ends, the radio returns to normal operation.


Note: IF the “Code Squelch” has been enabled on the selected channel, the “Message Call” feature cannot be enabled on the same channel.

TWO-TONE SELECTIVE CALL

The dealer can program the “Two-Tone Selective Call feature. The two-tone is sent when the **[PTT]** button and **[LAMP]** button are simultaneously pushed. After the two-tones are heard, release the keys.

SELECTABLE CTCSS

The dealer can program the “Selectable CTCSS” feature to temporarily change the CTCSS frequency on a channel. To enter the “Selectable CTCSS” mode, use the channel selector to select the channel, hold down the **[MONI]** button, press the **[DIAL]** key (the LCD display is shown below), and then use the channel selector knob to select a CTCSS frequency. The selected frequency is valid only in the “Selectable CTCSS” mode. To exit from this mode, hold down the **[MONI]** button and press the **[DIAL]** key. The LCD will return to the original display.



AUTO-RESPONDER

The dealer can program the “Auto-Responder” feature to work with the “Code Squelch” or the Selective Call” feature. When enabled and the radio receives a call with the correct code, the radio will automatically respond. One of the following respond modes can be programmed by the dealer:

- Alert Tone
- Radio ID Code
- Code stored in **[0]** key

CALL ALERT TONE

The dealer can program the “Call Alert Tone” feature to sound an alert tone when the correct DTMF tone is received. To stop the alert tone, press any key.

Care and Cleaning

- Avoid physical abuse of your radio such as carrying it by the antenna or remote microphone.
- Wipe the battery contacts with a lint-free cloth to remove dirt, grease, or other material that may prevent good electrical contact.
- When not in use, keep the accessory jacks covered with the protective cap.
- The case, controls, and keypad can be cleaned with a mild detergent and warm water. Avoid using strong chemicals.

Service

If you need service, contact your RELM Communication, Inc. dealer. If you find it inconvenient to have service performed by your local dealer, you may contact the factory below:

RELM Communication, Inc.
7100 Technology Dr.
W. Melbourne, FL 32904
Attn: Service Department

(800) 422-6281
www.RELM.com

RELM Wireless Corporation
7100 Technology Drive
West Melbourne, FL 32904
(800) 422-6281
(321) 953-7986
service@RELM.com